Installation TopFix / RecessFix [R1]

Do not damage the product when using a sharp knife to open the packaging! Fitting screws: Use a size-2 screwdriver (PO-ZIDRIVE) or use an electric screwdriver at it's lowest torque. Rail removal: Use a flat screwdriver of max. 6 mm wide. Only


use the original screws enclosed, to prevent malfunctioning from using too thick screw heads!

Model 25/AU10


WARNING

Young children can be strangled by loops in pull cords, chains, tapes and inner cords that operate the product. They can also wrap cords around their necks. To avoid strangulation and entanglement, keep cords out of

reach of young children. Move beds, cots and furniture away from window covering cords. Do not tie cords together. Make sure cords do not twist and create a loop. Install and use the included safety devices according to the installation instructions on these devices to reduce possibility of such an accident. According to EN 13120



Product width	Number of parts	
		()
30 - 90 cm	2	2
90 - 180 cm	3	3
180 - 270 cm	4	4
270 - 300 cm	5	5







For installation height on/ below 1.5m, the operation cord length is max 1cm. To adjust the operation cord length, push the tassel cap up to the headrail. Tie a knot as high as possible, then cut the cord under the knot and click the enclosed transparent part of the tassel on the cap.

push the tassel cap up the cord and tie a knot on the required height. Then cut the cord under the knot and click the enclosed transparent part of the tassel on the cap.

